

Cleaners Tested for 3D Laminate

Table 1.--Medical cleaners used during this evaluation, listed in order of application.

Number	Medical Cleaner	Manufacturer
1	Bleach (5 parts water to 1 part bleach)	Clorox
2	Citrace® germicide	Caltec, Ind.
3	Clorox® germicidal wipes	Clorox
4	Dispatch® spray with bleach	Caltec, Ind.
5	Lysol® spray disinfectant	Reckitt Benckiser
6	Precise™ hospital cleaner	Medline Industries, Inc.
7	Virex® II 256 cleaner – diluted per manufacturer’s instructions	Diversey, Inc.
8	Virex® II 256 cleaner – full strength.	Diversey, Inc.
9	Bleach-Rite® disinfecting spray	Current Technologies
10	Fade-A-Dyne® stain remover	Fade-a-Dyne
11	Fade-A-Dyne® blood remover	Fade-a-Dyne
12	Asepticare TB-II	Ecolab
13	Cavicide® surface disinfectant	Metrex
14	SaniZide Plus® germicidal solution	Safetec
15	Rescue Sporicidal Gel	Virox
16	Accel Cleaner Concentrate	Virox
17	Accel TB Wipes	Virox
18	Accel Intervention Wipes	Virox
19	Accel Prevention Wipes	Virox
20	Super Sani-Cloth germicidal wipes	PDI
21	Sani-Cloth HB germicidal wipes	PDI
22	Sani-Cloth Plus germicidal wipes	PDI
23	Sani-Cloth AF3 wipes	PDI
24	Sani-Cloth Bleach wipes	PDI
25	Prevantics Swab/Swabstick	PDI



INNOVATE YOUR SPACE

321 E 1st Street
 Centuria, WI 54824
 P: 800.969.9708
 F: 715.598.9022
custcare@stratisindustries.com
StratisIndustries.com

Table 2.--4 hours exposure results for commercial medical cleaners on the "5F" Nco kpcvg

Medical Cleaner	Laminate material		
	Vinyl Thermofoil		
	Specimen 1	Specimen 2	Specimen 3
Bleach 5:1	Moderate SI	Moderate SI	Moderate SI
Citrace® germicide	NE	Moderate SI	Moderate SI
Clorox® germicidal wipes	NE	NE	NE
Dispatch® spray with bleach	Moderate SI	Moderate SI	Moderate SI
Lysol® spray disinfectant	NE	NE	NE
Precise™ hospital cleaner	Moderate SI	Moderate SI	Moderate SI
Virex® II 256 cleaner – diluted per manufacturer’s instructions	NE	NE	NE
Virex® II 256 cleaner – full strength.	NE	NE	NE
Bleach-Rite® disinfecting spray	Moderate SI	Moderate SI	Moderate SI
Fade-A-Dyne® stain remover	Moderate SI	Moderate SI	Moderate SI
Fade-A-Dyne® blood remover	NE	Moderate SI	NE
Asepticare TB-II	NE	NE	NE
Cavicide® surface disinfectant	NE	NE	NE
SaniZide Plus® germicidal sln.	Moderate SI	Moderate SI	Moderate SI
Rescue Sporicidal Gel	NE	Moderate SI	NE
Accel Cleaner Concentrate	Moderate SI	NE	NE
Accel TB wipe	NE	NE	NE
Accel Intervention wipe	NE	NE	NE
Accel Prevention wipe	NE	NE	NE
Super Sani-Cloth germicidal wipe	NE	NE	NE
Sani-Cloth HB germicidal wipe	NE	NE	NE
Sani-Cloth Plus germicidal wipe	NE	NE	NE
Sani-Cloth AF3 wipe	NE	NE	NE
Sani-Cloth Bleach wipe	NE	NE	NE
Prevantics swab/swabstick	NE	NE	NE

Note: Inspection results after water rinse. Specimen was viewed at a multiple angles under fluorescent lights. SI=surface imperfection.